



FITTING INSTRUCTIONS FOR ECS0070BK ENGINE CASE SLIDERS SUZUKI GSX-R600 & GSX-R750 L1 & L2 (RIGHT HAND SIDE ONLY)



Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*

Right-hand side (as you sit on bike)

- Remove the right side fairing from the bike.
- Remove three M6 bolts as positioned (arrowed) above.
- Insert new cap head screws with washers through slider. There are three different lengths of bolt, please ensure they are fitted so no more than 30mm of thread protrudes from the slider ie; shortest to front of bike, longest to rear of bike and mid length to centre of slider.
- Offer up to bike.
- Tighten evenly to manufactures specified torque.
- Fit bubble sticker as shown above.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in resellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G Racing

Unit 5K, Blacknest Industrial Park, Blacknest Road, Alton, Hampshire, GU34 4PX

Tel: +44 (0)870 220 6380 Fax: +44 (0)1420 521101 www.rg-racing.com Email: info@rg-racing.com



**Instructions de montage pour ECS0070BK Protection carter moteur
SUZUKI GSX-R600 & GSX-R750 L1 & L2 (Coté droit uniquement)**



**LA FAÇON DONT LE KIT EST EMBALLE NE CORRESPOND PAS FORCEMENT A LA FAÇON DE MONTER LES PIECES SUR
LA MOTO.**

Notez que si les kits sont emballés avec des rondelles en caoutchouc servant à tenir les composants, *ces rondelles doivent être jetées.*

Coté droit assis sur la moto

- Enlever le carénage coté droit
- Enlever les 3 boulons M6 positionnés comme ci dessus.
- Insérer les nouvelles vis avec rondelles à travers la protection. Il y a 3 longueurs différentes de boulons. Assurez vous qu'ils soient installés de façon à ce qu'il n'y ai pas plus de 30mm de dépassement ; le plus court vers l'avant de la moto, le plus long vers l'arrière de la moto puis la restante pour le milieu de la protection.
- Monter le tout sur la moto.
- Serrer de façon égale aux couples adéquats.
- Mettre le sticker en gomme R&G.