



Parts Diagram



NO.	DESCRIPTION	QTY	PART #	
1	Yoshimura Ti Header	1	21922-704F	
2	Yoshimura Ti Tailpipe	1	21922-744	
3	Yoshimura Carbon Fiber Muffler Assy.	1	219221D220-RMA	
	Yoshimura Titanium Muffler Assy.		219221D720-RMA	
4	Short Exhaust Spring	3	RACE-SPX-1	
5	Medium Exhaust Spring	1	RACE-SPS-1	
6	8mm x 40mm Flanged Hex Head Bolt	1	M8X40H	
7	Aluminum Spacer	1	ALS-043	
8	Rubber Grommet	1	Z1023	
9	Aluminum Spacer	1	ALS-059	
**	AMA 94dB Sound Insert (Installed)	1	INS-14-K	
**	2m-MAX Sound Insert Kit	1	INS-2M28-K	
**	Spring Puller Tool	1	ST-200	
**	Yoshimura Sticker Sheet	1	17029	
**	Muffler Wash Plug	1	347PLUG	
OPTIONAL REPLACEMENT PARTS				
Spark Arrestor		SA-04-K		
Re-pack Kit		REPACK-RS4-PK11		



** Not shown on diagram.

- CAUTION: Exhaust system can be extremely hot. Let motorcycle cool down before beginning installation. Always wear hand and eye protection and take precautionary measures to avoid injury.
- WARNING: Always properly support vehicle with a stand and/or lift when servicing or performing any work. Unstable vehicles may present dangerous conditions and may cause property damage and/or personal injury.
- NOTE: Read through all instructions before beginning installation.


Removal

- 1. Remove right side panel.
- 2. Loosen exhaust clamp between muffler tailpipe and header connection.
- 3. Remove forward muffler chassis mount bolt.
- 4. While securely supporting the stock muffler assembly, remove rear muffler mount bolt and carefully remove muffler from header.
- 5. Remove the two header nuts and carefully remove the stock header.


Note: The stock exhaust port gaskets will be reused with the Yoshimura full-system. Inspect and replace if necessary.

Installation


1. Install (No. 8) *Z1023,* rubber grommet into muffler bracket.



2. Install (No. 7) *ALS-043* and (No. 9) *ALS-059* aluminum spacers into (No. 8) *Z1023*, rubber grommet as shown.



- 3. Install (No. 1) *21922-704F,* header using the stock header nuts. Do not torque at this time.
- Install (No. 2) 21922-744, tailpipe inlet over (No. 1) 21922-704, header outlet and align tailpipe chassis mount bracket to chassis mount. Secure using the stock chassis mount bolt. Do not torque at this time.
- Install (No. 3) *muffler*, onto (No. 2) *21922-744*, tailpipe outlet and align muffler mount bracket to muffler mount. Secure using (No. 6) *M8X40H*, 8mm bolt. Torque muffler mount bolt to 23 Nm (2.3 kg-m, 17 ft-lb).
- 6. Torque chassis mount bolt to factory specifications.
- 7. Torque header nuts to factory specification.
- 8. Install (No.4) *RACE-SPX-1*, short exhaust spring between muffler and tailpipe and between header flange and header using the *ST-200*, spring puller tool supplied in the kit.
- 9. Install (No. 5) *RACE-SPS-1*, medium exhaust spring between tailpipe and muffler.
- 10. Re-install right side panel.
- 11. Before starting vehicle, check for proper clearance between new exhaust system and rear suspension (i.e. tire, swingarm, brakes, rear shock, and etc.) If any problem is found, please carefully follow through the installation steps again. If problem still persists, please call Yoshimura Tech Department at (800) 634-9166 / in CA (909) 628-4722.
- 12. It is recommended that the muffler and tailpipe be wiped down with rubbing alcohol to remove oil and fingerprints. This will help prevent tarnishing of the finish after the exhaust is heated up.
 - Note: After starting motorcycle, it is normal for new exhaust system and muffler to emit smoke until oil residue burns off.



NO.	DESCRIPTION	QTY	PART #
1	6mm X 12mm Button Head Cap Screw	1	M6X12BHS
2	6mm Lock Washer	1	6MMLCKWSHR-TH
3	RS4 Spark Arrestor Ring 1.500"	1	RS4-RING-1500
4	AMA 94dB Sound Insert	1	INS-U
5	Yoshimura Exhaust	**	**

- 1 Using a 4mm Allen key, remove the bolt that secures the aluminum ring and sound insert to the muffler (see Parts Diagram for location).
- 2 Remove the sound insert from the muffler.
- 3 Inspect the sound insert for cracks or damage and replace if necessary.
- 4 Re-install sound insert and aluminum ring. Torque the sound insert securing bolt to 1.0 kg-m (7.3 lb-ft). NOTE: It is recommended that a low strength "Loc-tite" is used on the sound insert securing bolt.